

Installation is a breeze

- Dig a hole approximately 14" x 24" wide and 12" deep.
- Your New Mail Safe Mailbox is constructed with a pre-formed Bury-Line that's on the pedestal and is pre-measured to the correct installation height (38" to 42").
- The Mail Safe does not need any additional material to make it solid. Simply set it in the ground, replace the dirt, and let it set for a few days to become solid.

Assembly Instructions for Mail Safe Mailbox

The Mail Safe Pedestal Mailbox comes in 2 pieces in a box and only requires a Phillips head screwdriver for assembly. It comes partially pre-assembled (flag and doors are already installed) and all you need to do is attach the top half to the bottom half. In the box is a sealed plastic bag with 2 Keys, 4 screws and 4 washers. The easy-to-follow illustrations on the instructions guide you through the proper placement for the screws and washers.

Installation of the Mail Safe Pedestal is incredibly simple. For installation you have to dig a hole that's approximately 14" x 24" wide and 12" deep. The bottom the pedestal is flared out to the front and the back and is constructed with a pre-formed bury-line that is pre-measured to the correct installation height (38" to 42"). Once the ground is level simply set the Mail Safe in the ground, replace the dirt up to the bury-line, and let it set for a few days to become solid. The flared bottom with the combination of the dirt and soil on top of it provides all the support the Mail Safe Pedestal Mailbox needs. If you want extra support you can place a dry bag of cement on the flared end on the back of the pedestal or open the bag and put half of the cement on the front flange and half on the back flange, mix with a little water and then cover with dirt.

